



Templates for 17.25 Dia. x 21.6 Pitch Propeller

Open the file Wubba P\WVA Prop Blade Templates. Print 2 **FULL SIZE** copies on 8 1/2 x 14 paper.

Step 1. Use 3M77 spray adhesive to attach Template A to the Block's Bottom Face. Make off-cuts as indicated by Template A.

Step 2. Attach Template B to the Block's Back Face. Make offcuts as indicated by Template B.

Step 3. Attach Template C to the Block's Bottom Face (inboard portion).

Step 4. The Templates now identify the Leading and Trailing Edges of the eventual Propeller. At each location shown on the templates, make one corner-to-corner saw-cut straddling the Bottom and Back Faces. The saw-cut is to run from Leading Edge to Trailing Edge in a straight line. After completing all saw-cuts, material between the saw-cuts can be chipped away to reveal the Prop Blade's helical back-face. Sand the helical surface smooth.