

Step 1. Download the file "Wubba POWWA Insignia.pdf". Print a full-size **COPY** on 8 1/2 x 14 printer paper. On the **COPY**, mark the paper transport direction.  
Step 2. Select a contrasting Esaki tissue colour and cut a tissue panel sized as shown. Note tissue grain direction.  
Step 3. Apply a very light dusting of 3M77 to the **COPY's** printed surface. Adhere tissue panel shiney-side-up onto the printed **COPY**, in the location shown.  
Step 4. Load the **COPY** into the paper-feed-tray, with the tissue-side up, and with its' paper-transport direction same as in Step 1.



Step 5. Adjust your printer settings to print full size, in-colour. Print the coloured insignia onto the tissue paper attached to the **COPY**.  
Step 6. Carefully peel the tissue off of the **COPY**. Before covering the RH-top wing-panel with the tissue-panel bearing the insignia, let the ink air-dry for 24 hours.  
Step 7. Dope the tissue panel including the insignia, in the usual manner.  
Suggestions: Works best with pre-shrunk tissue. If tissue edges are not securely adhered, tape them to the **COPY**, before printing